

YES 60 FI / TU

2" x 6" Storefront System (Thermally Broken for YES 60 TU Only)

Weathering / Sealant Checklist

Item	N/A	Done	Instruction ⁽¹⁾	*Ref	
1.	☐	☐	Shims should be used at the head, sill, and jambs to ensure that frame is installed plumb, level, and square and to ensure sufficient perimeter space for use of backer rods and proper caulk beads.	pgs. 5-6	
2.	☐	☐	Sill flashing weep holes should be located at 1/4 points of the daylight opening.	pg.10	
3.	☐	☐	Apply sealant to the ends of the head, horizontal, and sill prior to assembly. Also seal the vertical mullion reglets at head, horizontal, and sill locations.	pg.12	
4.	☐	☐	Bend the tab on the end dam to engage with the groove on the sill flashing. Clean the flashing and the end dam and apply sealant and fasten the end dam to the flashing.	pg.14	
5.	☐	☐	At sill flashing splice, allow 3/8" splice joint between members. Remove the flashing nub. Apply sealant as directed in Detail 16, apply the silicone splice sleeve and tool for a complete seal. Seal the space at the front of the flashing.	pgs. 15-16	
6.	☐	☐	At flashing splice locations, apply bond breaker tape to the back of the sill prior to applying sealant between the ends of the flashing.	pg.16	
7.	☐	☐	Snap flat fillers on back side of head and jamb mullions where perimeter fasteners will be used. Match drill prior to installing anchors. Seal all flashing anchor heads.	pg.21	
8.	☐	☐	Just prior to installing the frame onto the sill flashing, place a bead of sealant along the top of the back leg of the flashing. Set frame in place, plumb and level.	pg.21	
9.	☐	☐	After anchoring the frame, seal all perimeter anchor fastener heads at head, sill, and jambs.	pg.28	
10.	☐	☐	Install backer rods and perform perimeter seal at head, sill, and jambs at the exterior and the interior.	pg.28	
11.	☐	☐	Install water deflectors on the end of each horizontal member. Apply sealant along the three edges and tool. Also seal vertical gasket reglet in the pocket.	pg.30	
12.	☐	☐	Glazing gaskets should be cut to a length of daylight opening + 1/4" per foot of daylight opening. Vertical gaskets should run through. The ends of the horizontal gaskets should be sealed to the vertical gaskets.	pg.36	
13.	☐	☐	Each lite of glass should have 2 setting blocks located at quarter points of the daylight opening. Set the glass and place anti-walk blocks in deep pockets.	pgs. 37-38	

 Denotes short video clips (YES 45 TU Center Set shown, YES 60 FI / TU similar) for this step are available for viewing at www.ykkap.com/productmaster

(1) Please review the entire installation manual prior to fabrication and installation. This checklist is provided as a quick review during and after installation. Visit www.ykkap.com/productmaster.

Project Name: _____