





Item	N/A	Done	Instruction <sup>(1)</sup>	*Ref	
1.		<input type="checkbox"/>	Sill flashing must be used. If opening is over 24' wide, flashing should be spliced every 12 – 15 feet. 5/16" weep holes should be located in the front of the flashing at the centerline of each vertical mullion and jamb and at the centerline of each daylight opening.	pg.8	
2.		<input type="checkbox"/>	Glass stops should be cut to a length of daylight opening minus 1/32".	pg.15	
3.		<input type="checkbox"/>	Mullion end caps should be fastened and sealed to the ends of all vertical mullions and jambs. See <b>Detail 14</b> .	pg.19	
4.		<input type="checkbox"/>	Prior to assembly, apply sealant to horizontals as shown in <b>Detail 16</b> (similar to Inside Glazing).	pg.20	
5.		<input type="checkbox"/>	Bend the tab on the end to engage with the groove on the sill flashing. Clean the flashing and the end dam and apply sealant to the end of the sill flashing, and fasten the end dam to the flashing. See <b>Detail 21</b> .	pg.22	
6.		<input type="checkbox"/>	Flashing should be installed level with a minimum of 3/8" caulk joint underneath. At sill flashing splice, allow 3/8" splice joint between members. Remove the flashing nub. Apply sealant as directed in <b>Detail 24</b> , apply the silicone splice sleeve, and tool for a complete seal. Seal the space at the front of the flashing. All anchors that penetrate sill flashing should be sealed.	pgs. 23-24	
7.		<input type="checkbox"/>	Just prior to setting the frame in the flashing, a continuous bead of sealant should be applied to the top of the upturned leg on the sill flashing. All frames should be installed level, square, and true. Perimeter caulk joint width should be a minimum of 3/8" under the sill flashing and a minimum of 3/8" at the head and jambs. The fastener that attaches the sill to the flashing should not penetrate the sill flashing. All perimeter anchor heads should be sealed over. See <b>Detail 29</b> .	pg.26	
8.		<input type="checkbox"/>	Apply sealant to all vertical/horizontal seams within the glass pockets. See <b>Detail 30</b> .	pg.27	
9.		<input type="checkbox"/>	Apply perimeter sealant at the interior and exterior of the system. Do not seal between the sill and the flashing at the exterior. Perimeter caulk bead should be under the sill flashing. See <b>Detail 31</b> .	pg.27	
10.		<input type="checkbox"/>	Water deflectors are required at the ends of all intermediate horizontals. Attach water deflectors with pre-applied tape and seal perimeter of water deflector. See <b>Detail 32</b> .	pg.28	
11.		<input type="checkbox"/>	Interior fixed glazing gaskets should be installed first. Vertical gaskets should be cut to a length of daylight opening plus 3/4" plus 1/4" per foot of daylight opening. 3/8" should be trimmed off the vertical gasket legs at both ends as shown on <b>Detail 40</b> . Horizontal gaskets should be cut to a length of daylight opening plus 1/4" per foot of daylight opening. Horizontal/vertical gasket corners should be sealed. Exterior wedge gaskets should be cut to a length of daylight opening plus 1/4" per foot of daylight opening. Seal all gasket corners.	pg.33	

 Denotes short video clips for this step are available for viewing at [www.ykkap.com/productmaster](http://www.ykkap.com/productmaster)

(1) Please review the entire installation manual prior to fabrication and installation. This checklist is provided as a quick review during and after installation. Visit [www.ykkap.com/productmaster](http://www.ykkap.com/productmaster).